

Omni-tuff Suggested Procedure Specification

Heat-shrinking with a Ripack Gun (03-RP3000)

With Omni-tuff Plastics Dispenser

Ensure the gun is pre-set up according to the Ripack Instruction Manual and connected correctly to a suitable gas bottle.

1. Pull one plastic pallet bag from the roll of plastic on the dispenser (A).
2. Open the bag and slide it over the pallet. Pull down towards the ground until the plastic is touching the floor (B).
3. Put a heavy duty welding glove onto the hand that will not be holding the heat gun.
4. Turn the gas on by turning the tap, and slide the red priming button on the lead, three times (C).
5. Squeeze the trigger on the vertical section of the gun (D).
6. Hold the gun 10-15 centimetres away from the base of the pallet bag (E).
7. Seal the bottom of the bag by moving slowly around the pallet, to achieve a sealed edge (F).
8. Seal the sides of the bag by holding the gun the same distance away and moving slowly around the pallet. Ensure that the flame comes in near proximity to the plastic, causing it to shrink and cling to the item inside the bag (G).
9. Continue with the same procedure with the top of the pallet bag (H).
10. Your finished product will be similar to image (I).

For further help and support, contact the team at Omni-tuff on:

T: 1300 662 987

E: sales@omnituff.com

